



3
YEAR

SATISFACTION
GUARANTEE

model VH200-JP

WHOLE ROOM HEATER

OWNER'S GUIDE

ヒーター取扱説明書

READ AND SAVE

THESE INSTRUCTIONS

ご使用になる前に本書をよくお読み
のうえ、正しくお使いください。また、
大切に保管してください。

vornado.jp

製品には万全を
期しております。

万が一不具合
がありましたら、
下記へご連絡く
ださい。

vornado.jp
0120-390-747
info@vornado.jp

目次

| | | | |
|---------------|----|--------------|----|
| 安全上のご注意 | 4 | 保管方法 | 12 |
| 安全機能 | 8 | リセット方法 | 12 |
| 各部名称 | 9 | 故障かな? | 13 |
| 操作方法 | 10 | 製品保証 | 14 |
| お手入れ方法 | 11 | | |

English p. 15

安全上のご注意

ご使用前に必ずすべてお読みください。

本取扱説明書およびその他添付書類は、本製品の付属品であり、安全上のご注意、ご使用方法、処分方法などの重要事項が記載されています。本製品を安全に正しくご使用いただくために、ご使用前に必ずお読みください。また、これらの書類は大切に保管し、所有者が変わる際には本製品に添付してお渡してください。取扱説明書の最新版については、vornado.jpをご確認ください。

本取扱説明書では次のような注意事項を記載しています。

⚠ 危険

この欄は誤った取扱いをした際に、死亡や重傷を負う危険性の高い項目を示しています。危険防止のためこれらの警告は必ずお守りください。

⚠ 警告

この欄は誤った取扱いをした際に、死亡や重傷、傷害または物的損害を負う危険性が中程度ある項目を示しています。

⚠ 注意:

この欄は誤った取扱いをした際に、軽度および中程度の傷害または物的損害を負う危険の可能性がある項目を示しています。

⚠ 重要事項:

この欄は本製品の取扱いに関する追加の情報を示しています。

使用目的: 本製品は一般家庭、オフィスなど屋内用です。この製品は床置き専用です。業務用ではありません。このヒーターは、シャワールームや浴室などの濡れた場所で使用しないでください。本取扱説明書に従わず、本製品を目的外の用途に使用された場合、または不当に製品を改造された場合に生じる損害または傷害について、メーカーは一切責任を負いません。またそのような場合、本製品に関する保証の適用外となります。

⚠ **警告-** 火災、感電、ケガなどを防止し、安全に正しくご使用いただくために、以下の注意事項を守ってください。

使用上お守りいただく内容を図記号で説明しています。
⓪ してはいけない内容を示しています。
⓫ しなければならない内容を示しています。

⚠ 警告

お子様や不慣れな方への危険性:

- ⓫ 本製品の対象年齢は12歳以上です。安全にご使用いただくために、身体的、知覚的、精神的なハンディキャップのある方(お子様を含む)や不慣れな方がご使用になる場合は、責任を持てる方の指導または監督のもとお使いください。
- ⓪ お子様の本製品で遊ばないようにしてください。
- ⓪ 本製品のお手入れは、お子様だけで行わないでください。必ず責任を持てる方が付き添ってください。
- ⓪ 本製品および梱包材は玩具ではありません。お子様の手の届く場所に保管しないでください。

⚠ 警告

誤った取扱いをした場合に生じる危険性: 人的及び物的損害を負わないよう次の指示に従ってください。
⓪ 屋外や天候の影響を直接受ける環境では使用しないでください。

- ⓪ 棚や机などの高い場所で使用しないでください。必ず床に置き、立てて使用してください。
- ⓪ このヒーターは、シャワールームや浴室などの濡れた場所で使用しないでください。浴槽やプールなどの水の中に落ちる可能性のある場所には、絶対に置かないでください。
- ⓪ 電源コードは、絨毯の下を這わせたりラグなどの敷物で覆ったりしないでください。
- ⓪ 家具や家電機器など重いものを電源コードの上に載せないでください。電源コードにつまづくことがないように出入りの多い場所には設置しないでください。使用中は電源コードを束ねないでください。
- ⓪ 製品が誤作動した場合、または落下や何らかの理由で破損した場合には使用しないでください。危険を避けるために、製品を廃棄するか、(株)エヌエフ貿易に点検および修理を依頼してください。
- ⓪ 本体を物で覆ったり、濡らしたりしないでください。
- ⓫ 使用しない時や、長時間外出する場合は電源プラグをコンセントから抜いてください。
- ⓪ コンセントの真下に置かないでください。
- ⓪ 室外に出るのに付き添いが必要な方々が集まっている小部屋では使用しないでください。

⚠ 危険

火災や感電の危険性: プラグをコンセントにつないでいる時に製品内部の銅線や部品を触ると、死亡する危険性があります!

- ⓧ 屋外や天候の影響を直接受ける環境では使用しないでください。
- ⓧ 本製品を濡れた場所や浴槽、シャワールームで使用しないでください。
- ⓧ 本製品を水に浸けないでください。また、モーター部分に水が入らないように注意してください。
- ⓧ 電源コードやプラグが破損した場合は、製品を使用しないでください。電源コードが破損している場合は、危険を避けるために、(株)エヌエフ貿易に修理を依頼してください。
- ⓧ 火災や感電の危険性を避けるため、後付けの速度調節器を使用しないでください。
- ⓧ 電源コードを引っ張ったり押さえたりしないでください。本体を持たずに電源コードだけを持って本製品を移動させないでください。
- ⓧ 本体の開口部に異物を入れないでください。火災や感電、また故障の原因になります。
- ❶ お手入れの前には、必ず製品のプラグをコンセントから

抜いてください。安全のため、雷雨時にはコンセントからプラグを抜いてください。またプラグをコンセントから抜く際は、電源コードを持たず必ずプラグを持って抜いてください。

⚠ 警告

火傷の危険性

- ⓧ 人やペットの毛、衣類などを乾かすために使用しないでください。
- ⓧ ご使用中に熱くなる場合がありますので、素肌が触れないようにしてください。ヒーターを移動させる時は、取っ手を持って移動させてください。
- ❶ 家具、枕、寝具、紙類、衣類、カーテンなどの燃えやすいものを、吹出口から少なくとも1m(3フィート)遠ざけてください。本体の側面と背面からも遠ざけてください。

ⓧ 警告: 過熱を避けるため、本製品を物で覆わないでください。

⚠ 注意

人的傷害および物的損害を避けるため、すべての指示に従ってください。

- ❶ プラグを差し込んだ時にコンセントに緩みがあると、プラグの過熱や変形につながります。緩みのあるコンセントの使用は停止してください。緩んだコンセントや古いコンセントは専門業者に修理を依頼してください。
- ⓧ 同じコンセントで、電力を多く使用する機器、例えば掃除機や丸鋸と同時に使用しないでください。
- ⓧ 同じコンセントで、速度調節ができる機器、例えばブレンダーや速度調節のできる扇風機と同時に使用しないでください。
- ⓧ 雷サージプロテクターは使用しないでください。
- ⓧ 電源をオン/オフするタイマーはどのような種類でも使用しないでください。
- ⓧ ヒーターは、RV車やボートなど、DC/ACコンバーターで変換したAC電源を利用している乗り物では使用しないでください。
- ⓧ 感電、火災、または故障の原因になるため、吹出口や吸気口などの開口部に異物を入れないでください。
- ❶ 使用しない時は必ずプラグをコンセントから抜いてください。必ずスイッチを切ってからプラグを抜いてください。
- ❶ 必ず本製品の電源プラグを直接コンセントに差し込んでください。延長コードやテーブルタップを使用しないでください。
- ❶ 必ず本取扱説明書に従って本製品を使用してください。本取扱説明書に従わず使用すると、火災、感電、人的傷害の原因となります。

- ❶ 本製品には、過熱した場合に自動的に運転を停止する過熱時停止装置が備わっています。再運転させる場合は、「過熱時停止装置のリセット方法」を参考に解除してください。
- ⓧ 過熱停止装置が正しく作動しない可能性があるため、コンセントタイマーは使用しないでください。

❶ 電源: 必ず100V~50/60Hzのコンセントをご使用ください。

⚠ 整備に関する警告—火災、感電、ケガの危険を避けるため、以下の指示に従ってください。

- ❶ 本取扱説明書に従い、定期的に本製品のお手入れをしてください。お手入れの前には必ず電源を切り、プラグをコンセントから抜いてください。ガソリン、シンナー、溶剤、アンモニアなどの化学薬品を使用しないでください。「お手入れ方法」を参考にしてください。
- ⓧ 本体を絶対に開けないでください。修理はすべて(株)エヌエフ貿易に依頼してください。
- ❶ 環境に配慮し、梱包材は自治体のルールに従って処分してください。

取扱説明書は大切に保管してください。

安全機能

熱くならない本体:
高温設定にしても表面が熱くなりません。

過熱時停止装置:
送風が妨げられると、過剰な温度上昇を防ぐために電源が切れます。



指の入りにくいデザイン
安全性に配慮

転倒時OFFスイッチ:
10度以上傾くと運転が停止します。

転倒時: 本体が転倒すると運転が停止します。平らな場所で本体をまっすぐに立てると、運転が再開します。

各部名称

サーモスタット(室温設定)

電源ライト
ヒーター使用時に赤いライトが点灯します。



吸気口

電源スイッチ ①
ON (I)
OFF (O)


モード切替スイッチ
III (高温)
II (中温)
I (低温)

吹出口

操作方法

使用を開始する前に、破損している箇所がないか点検してください。万が一破損が見つかった場合には、絶対に使用しないでください。その場合は、直ちに(株)エヌエフ貿易までご連絡ください。

1. ヒーターを移動させる時は、本体背面の持ち手を使って持ち上げてください。
2. 温風が遮られないような位置に設置してください。
3. プラグをコンセントに差し込んでください。




4. 電源スイッチ ① をONにして、モード切替スイッチ ② でモードを選択してください。次にサーモスタット(室温設定)を時計回りに回して最大にします。室温が適温になったら、ファンが止まる位置までサーモスタットをゆっくり回して戻してください。

*初回通電時に臭いがする場合がありますが、ご使用に問題はございません。

お手入れ方法

このヒーターは大量の空気を動かしますので、定期的なお手入れが必要です。点検を兼ねて、週に1回程度は本体表面のホコリを取り除いてください。修理が必要な場合は、直ちに(株)エヌエフ貿易までご連絡ください。修理依頼の詳細については、製品保証書をご確認ください。

1. お手入れを始める前に必ずプラグをコンセントから抜いてください。
2. ヒーター前面の吹出口に溜まったホコリを家庭用掃除機の付属ブラシを使用して吸い取ってください。



Tip このヒーターは大量の空気を吸い込みますので、週に1回程度エアダスターで内部に溜まったホコリやチリ、髪の毛などを吹き飛ばしてください。内部に溜まったゴミは臭いの元になります。

3. ヒーター背面と側面の吸気口に溜まったホコリを家庭用掃除機の付属ブラシで吸い取ってください。
4. 本体は乾いた柔らかい布で拭いてください。


注意: VORNADO純正以外の部品を使用して、修理をしないでください。

保管方法

オフシーズンや長期間使用しない場合は、下記の要領に従って保管してください。製品が長持ちします。

Tip 保管する前にお手入れしてください。

1. プラグをコンセントから抜いてください。電源コードを緩く束ねます。
2. 購入時の箱が残っていれば箱にヒーターを入れ、箱がない場合はカバーをして、ヒーターにホコリが溜まらないようにします。
3. 湿気の少ない涼しい場所に保管してください。



廃棄

環境に配慮し、梱包材は自治体のルールに従って処分してください。


リセット方法

過熱時停止装置のリセット方法

ボルネードのヒーターには、温度の過剰な上昇を防ぐために自動停止機能が備わっています。何らかの理由で吸気口や吹出口がふさがれると、自動的に送電を停止します。その場合、手動でリセットしてください。

1. 電源を切り、プラグをコンセントから抜いてください。
2. 送風を妨げている障害物を取り除きます。
3. 5～10分間待ってヒーターを冷まします。
4. 使用したい場所に置いて、再度プラグをコンセントに差し込んでください。
5. 電源スイッチを入れると、正常に運転し始めます。

注意: 上記の操作を行っても正常に戻らず、過熱時停止装置が繰り返し作動する場合には、直ちに(株)エヌエフ貿易までご連絡ください。



故障かな？

トラブル

電源が入らない

考えられる原因と解決方法

プラグが外れていませんか。プラグをコンセントに差し込んでください。

ブレーカーが落ちたり、ヒューズが切れたりしていませんか。ブレーカーを元に戻すか、ヒューズを交換してください。「安全上のご注意」をご参照ください。

本体が過熱し、過熱時停止装置が作動していませんか。「リセット方法」をご参照ください。

転倒時OFFスイッチが作動して、通電が停止していませんか。ヒーターを水平な場所に置いてください。「安全機能」をご参照ください。

本体が破損しているか故障しています。直ちに使用を中止し、プラグをコンセントから抜いてください。(株)エヌエフ貿易までご連絡ください。

部屋がなかなか暖まらない

モード設定をⅢ(高温)にし、サーモスタットの室温設定を最大にしてください。

熱が逃げないように、ドアや窓を閉めてください。

室内全体が暖まるまでに4～5分かかります。しばらく様子を見てください。

電源を入れても温風が出ない

電源を切り、プラグをコンセントから抜きます。本体底の丸いボタンを4、5回押して、引っかかりがないか確認してください。電源コードが本体と床の間に挟まらないよう注意しながら本体を平らな場所に設置し直します。プラグをコンセントに差し込んで、電源スイッチを入れてください。モード切替スイッチをⅢ(高温)、サーモスタットを最大に設定して運転してください。



製品保証

製品には万全を期しておりますが、万が一不具合がありましたら以下の保証規約に基づき対応させていただきます。

保証規約

製品の修理をご希望の際には、必ず事前に販売業者あるいは代理店にお問い合わせください。

製品保証は、それぞれの国で販売されているモデルにのみ適用されます。製品の銘板にある安全法適合性検査マークを見て仕様対象国をご確認ください。修理を希望する際には、必ずご購入を証明できるレシート等を提出してください。保証期間終了後の修理につきましては有料となります。

本取扱説明書に記載のない使用または不当な修理や改造(変圧器の使用も含む)による故障や損傷については保証の適用外となり、メーカーは一切責任を負いません。故意に銘板を剥がしたとみられる場合にも、保証の適用外となります。

ボルネード・エア日本総代理店
(株)エヌエフ貿易
〒176-0024
東京都練馬区中村3-38-8
TEL: 0120-390-747
www.vornado.jp

指定外の業者による修理や純正品以外の交換部品の使用は推奨しません。その結果により生じる不具合は、サポートサービスや製品保証の適用外となります。

本保証規約はその製品が販売されている国においてのみ有効です。

We expect this product to be perfect.

If it is not, we will make it right.

vornado.jp
0120-390-747
info@vornado.jp



カンザス州アンドーバーで設計およびエンジニアリング

© 2024 Vornado Air LLC Andover, KS 67002 U.S. 仕様は予告なく変更される場合があります。Vornado®は、Vornado Air LLCが所有する商標です。

CONTENTS

| | | | |
|------------------------------|----|-----------------------|----|
| Important Instructions | 17 | Storage..... | 26 |
| Safety Features | 22 | Reset Heater | 26 |
| Controls..... | 23 | Troubleshooting | 27 |
| How to Use | 24 | Warranty..... | 28 |
| Cleaning | 25 | | |

IMPORTANT INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USING

This owner's guide and any additional inserts are considered part of the product. They contain important information about safety, use, and disposal. Before using the product, please familiarize yourself with all operating and safety instructions. Please keep all documents for future reference and pass these documents on, together with the product, to any future owner. Please refer to vornado.jp for the most current version of our owner's guide.

The following Warning messages are throughout this owners guide:

DANGER

DANGER indicates a hazard with a HIGH level of risk which, if not avoided, will result in death or serious injury. Please pay special attention to any instructions given to avoid this threateningly dangerous risk.

WARNING

WARNING indicates a hazard with a MEDIUM level of risk which, if not avoided, could result in death, serious injury, minor or moderate injury or potential property damage.

CAUTION


CAUTION indicates a hazard with a LOW level of risk which, if not avoided, could result in minor or moderate injury or potential property damage.

IMPORTANT INSTRUCTIONS



Indicates additional information that will assist in the care of handling of the device.

INTENDED USE: This product is intended to heat and circulate the air in indoor living spaces only. This product is intended for floor use only. This product is not intended for commercial or industrial use. This

heater is not intended for use in bathrooms, laundry areas, and similar damp locations. The manufacturer assumes no responsibility for damage or injury due to unauthorized use or product modification. Failure to follow these directions will void the product warranty.


 **WARNING** – When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

The following symbols indicate precautions that must be followed:




-  Indicates actions that **must not** be done.
-  Indicates actions that **must** be done.

WARNING

Risk to Children and Other at Risk Groups of People.




-  This appliance can be used by children aged from 12 years and above. This appliance is not intended for use by persons (including children) with reduced

physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.








-  Children shall not play with the appliance.
-  Cleaning and user maintenance shall not be made by children without supervision.
-  This product and its packaging material are not toys and should be kept out of reach of children.

WARNING

Risk from Unintended Use and Handling. Please take care to follow these guidelines to avoid risks to people or property.









-  **Do Not** use this product outdoors or directly exposed to weather.
-  **Do Not** use this product on an elevated surface such as shelf or desktop. Use only while placed on the floor. Operate only in the upright position.
-  This heater is not intended for use in a shower, bath

area or wet environment. Never locate heater where it may fall into bathtub, swimming pool or other water container.

-  **Do Not** run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings.
-  **Do Not** route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over. Do not bundle the cord when in use.
-  **Do Not** operate after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to NF Imports for examination and/ or repair in order to avoid a hazard.
-  **Do Not** cover the heater or get the heater damp or wet.
-  Always unplug when not in use or when leaving the dwelling or premises for extended periods of time.
-  **Do Not** place the heater directly below a socket outlet.
-  **Do Not** use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

DANGER

Risk from Electrical Shock. Contact with wires or components that are under voltage could be potentially fatal!

-  **Do Not** use this product outdoors or exposed to weather or elements.
-  **Do Not** use this product on wet surfaces, in bathtub or shower.
-  **Do Not** immerse this product in water or allow water to drip into the motor housing.
-  **Do Not** use this product if it has a damaged power cord or plug. If the power cord is damaged, it must be replaced by NF Imports in order to avoid a hazard.
-  To reduce the risk of fire or electrical shock, do not use this product with any solid state speed control device.
-  **Do Not** stretch the power cord or put the cord under strain. Never use the power cord as a handle.
-  **Do Not** insert or allow foreign objects to enter any input or output opening as this may cause risk of electric shock or fire, or damage the product.
-  Always turn off and unplug the unit before cleaning.

Power off and unplug during electrical storms. To disconnect from outlet, grasp and pull only the plug, not the power cord.

WARNING

Risk of burn.

- ⊘ **Do Not** use heater to dry human or animal hair or articles of clothing.
- ⊘ **Do Not** let bare skin touch hot surfaces, this heater is hot when in use. Use handles when moving this heater.
- ⓘ Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 1m (3 feet) from the front of the heater and keep them away from the side and rear.

 **Warning: In order to avoid overheating, do not cover the heater.**

CAUTION

Please pay attention to any instructions given to avoid personal injury or property damage.

- ⓘ A loose fit between wall outlet (receptacle) and plug may cause overheating and distortion of the plug. Discontinue use of the product in this outlet. Contact qualified electrician to replace loose or worn outlet.
- ⊘ **Do Not** use this heater on a circuit that is shared with another high power device, such as a vacuum or circular saw.
- ⊘ **Do Not** use this heater on a circuit that has a variable speed device operating, such as a blender or variable speed fan.
- ⊘ **Do Not** use this heater on a surge protected circuit.
- ⊘ **Do Not** use this heater with any kind of timer designed to turn the unit on or off.
- ⊘ **Do Not** use this heater in an RV, boat, or any application where a DC/AC converter is converting battery power to AC power.
- ⊘ **Do Not** insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an

electric shock or fire, or damage the heater.

- ⓘ Always unplug heater when not in use. To disconnect heater, turn controls to off, then remove plug from outlet.
- ⓘ Always plug heaters directly into wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power).
- ⓘ Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- ⓘ This heater is equipped with a thermal safety shut-off system, designed to turn off the heater when an internal overheating condition is detected. See How to Use "RESETTING YOUR VORNADO HEATER" to determine how to check and reset the heater.
- ⊘ In order to avoid a hazard due to inadvertent resetting of thermal cutout, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

ⓘ **ELECTRICAL CONNECTION:** Only a proper 100V~50/60Hz AC outlet may be used to connect to public power supply.

 **SERVICING WARNING—To reduce risk of fire, electrical shock and injury to persons, observe the following:**

- ⓘ Clean your product regularly, only as is instructed in this manual. Prior to cleaning, turn off the power on your product and unplug. Do not use gasoline, thinners, solvents, ammonias or other chemicals for cleaning. Refer to the CLEANING instructions provided.
- ⊘ Do not open housing. All service and/or repairs must be done by NF Imports.
- ⓘ Dispose of all packaging materials in an environmentally responsible manner.

SAVE THESE INSTRUCTIONS

SAFETY FEATURES

COOL-TOUCH CASE
Safe to touch, even on high heat setting.

AUTOMATIC SAFETY SHUT-OFF SYSTEM
If airflow becomes blocked, power to heater is shut off to prevent overheating.




FINGER-FRIENDLY DESIGN
Resists curious fingers.


AUTOMATIC TIP-OVER PROTECTION
If tipped more than 10 degrees in any direction, power to heater is cut.

TIP-OVER: If heater tips over, safety shut-off system cuts power to heater. Position heater back in upright position and power is restored.

CONTROLS

THERMOSTAT
POWER INDICATOR LIGHT
The red light illuminates to indicate the heater is On.




POWER 
On (I)
Off (O)



AIR INLET
AIR OUTLET
MODE
High Heat (III)
Medium Heat (II)
Low Heat (I)

HOW TO USE

Before use, check appliance for visible damage. DO NOT USE THIS HEATER if there is evidence of damage. If any damage is found, contact NF Imports.

1. Use integrated handle on back of heater for lifting and carrying.
2. Position heater so airflow is not obstructed.
3. Plug power cord into standard grounded wall outlet.




4. Press Power button  and select Mode . Next, set thermostat to highest setting by turning clockwise. When room reaches desired comfort level, turn thermostat slowly counterclockwise until heat cycles off.


*There may be a faint odor when the power is turned on for the first time, but this is normal.

CLEANING

Because your heater moves a substantial amount of air, it will need regular cleaning. Cleaning the outside of the heater is recommended on a weekly basis. If service is required, return your heater to NF Imports. See WARRANTY for instructions.

1. Unplug heater before cleaning.
2. Use brush attachment on household vacuum cleaner to vacuum any accumulated dust off the Front Outlet Grille.



 **Tip** You should periodically blow out the heater with pressurized air to keep heat element and motor clear of dust, hair and debris that can build up inside the heater as it moves air during use. This also eliminates unwanted odors caused by accumulation of these particles inside the unit.

3. Use brush attachment on household vacuum cleaner to vacuum any accumulated dust off Air Inlets on back and sides of heater.
4. Wipe down the entire heater with a soft, dry cloth.

Note: Do not modify the product with any aftermarket accessory.


STORAGE

During the off-season or after extended periods of non-use, you may choose to store your heater. To ensure long life of the product, it is recommended to store your heater by following these instructions:



Cleaning is recommended before storage.

1. Unplug power cord and bundle loosely.
2. Cover, or place back in retail carton if available. This prevents heater from accumulating dust over time.
3. Store heater in cool and dry location.



DISPOSAL

Dispose of all packaging materials in an environmentally responsible manner.


RESET HEATER

RESETTING YOUR VORNADO HEATER

Your Vornado Heater has a multilevel safety shut-off system designed to prevent overheating. Overheating may occur when the inlets or outlet are blocked. If this happens, the safety shut-off system cuts power to the heater and you must manually reset the heater.

1. Power heater off, then unplug power cord.
2. Remove any obstructions.
3. Wait 5–10 minutes, allowing heater to cool down.
4. Plug in power cord and place heater in desired position.
5. Press Power button On. Your Vornado Heater should now function normally.

Note: If the safety shut-off system repeatedly shuts off your heater or if it will not reset after following the above procedure, contact NF Imports.



TROUBLESHOOTING

PROBLEM

Unit fails to power on.

POSSIBLE CAUSE AND SOLUTION

Unit is not plugged in. Plug Power Cord into electrical outlet.

Household circuit breaker has tripped or blown fuse. Reset circuit breaker or replace fuse. See IMPORTANT SAFETY INSTRUCTIONS.

Unit has overheated. Automatic Safety Shut Off has initiated. See RESET HEATER.

Tip-over switch on bottom of unit has been tripped and safety shut-off system has cut power to heater. Place heater on level surface. See SAFETY FEATURES.

Unit is damaged or in need of repair. Cease usage and unplug. Contact NF Imports for assistance.

Unit is not producing sufficient amount of heat.

Ensure unit is set to High Heat and thermostat is set to highest temperature setting.

Close all doors and windows to trap heat.

Allow unit to fully circulate heat throughout room; may take several minutes.

Unit is powered on but there is no heat.

Press the Power button Off and unplug unit. A cylindrical plunger is on bottom of unit. Push in 4-5 times, ensuring it is not stuck. Set unit down on flat surface. Ensure power cord is not under unit. Plug unit in and press Power button On. Turn to highest heat setting.



WARRANTY

We expect this product to be perfect. If you're not satisfied with this product, let us know.

Warranty Terms and Conditions:

Please contact the retailer where purchased or contact the authorized importer before returning the product for a warranty claim. The product warranty will be honored on models that are being used in the country intended. See the silver rating label on the product to confirm the safety testing marks which identify the specific country of intended use. Please provide a copy of your receipt with the defective product when returning to the authorized location. Repairs performed after the warranty period, are subject to a charge.

The manufacturer assumes no responsibility for damage or injury caused by failure to follow these instructions, improper product

use or unauthorized product modification. Improper product use includes using an external device that alters or converts the voltage or frequency of electricity. Such use will invalidate the product warranty. The product will be considered modified if the rating label has been removed, thus making the warranty void.

Repair by an unauthorized service center or use of non-approved replacement parts is not recommended and any consequences will not be covered by support services or product warranties.

Shipping a Vornado product to a country not intended for use, will void all warranties.



Designed and engineered in Andover, KS

© 2024 Vornado Air LLC Andover, KS 67002 U.S. Specifications subject to change without notice. Vornado® is a trademark owned by Vornado Air LLC.

