



3

YEAR
SATISFACTION
GUARANTEE

Model 80X-JP

**WHOLE ROOM CIRCULATOR
OWNER'S GUIDE**

サーキュレーター取扱説明書

**READ AND SAVE
THESE INSTRUCTIONS**

ご使用になる前に本書をよくお読みのうえ、正しくお使いください。また、大切に保管してください。

vornado.jp

We expect this
product to be
perfect.

If it is not, we
will make it
right.

vornado.jp
0120-390-747
info@vornado.jp

CONTENTS

Important Instructions	4	Cleaning	10
Features	8	Troubleshooting	11
How to Use	9	Warranty.....	12

日本語 p. 13

READ ALL INSTRUCTIONS BEFORE USING.

IMPORTANT INSTRUCTIONS

This owner's guide and any additional inserts are considered part of the product. They contain important information about safety, use, and disposal. Before using the product, please familiarize yourself with all operating and safety instructions. Please keep all documents for future reference and pass these documents on, together with the product, to any future owner. Please refer to vornado.jp for the most current version of our owner's guide.

The following Warning messages are throughout this owners guide:

DANGER

Indicates a hazard with a HIGH level of risk which, if not avoided, will result in death or serious injury. Please pay special attention to any instructions given to avoid this threateningly dangerous risk.

WARNING

Indicates a hazard with a MEDIUM level of risk which, if not avoided, could result in death, serious injury, minor or moderate injury or potential property damage.

IMPORTANT INSTRUCTIONS

Indicates additional information that will assist in the care of handling of the device.

The following symbols indicate precautions that must be followed:

-  Indicates actions that **must not** be done.
-  Indicates actions that **must** be done.

INTENDED USE: This product is intended to circulate the air in indoor living spaces only. This product is for floor use only. This product is not intended for commercial or industrial uses.

The manufacturer assumes no responsibility for damage caused by failure to follow these instructions or improper product use. Any such actions will invalidate the product warranty.

WARNING – When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

WARNING

Risk to Children and Other at Risk Groups of People.

-  This appliance can be used by children aged from 12 years and above. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
-  Children shall not play with the appliance.
-  Cleaning and user maintenance shall not be made by children without supervision.
-  This product and its packaging material are not toys and should be kept out of reach of children.

WARNING

Risk from Unintended Use and Handling. Please take care to follow these guidelines to avoid risks to people or property.

-  **Do Not** use this product outdoors or directly exposed to weather.
-  **Do Not** insert fingers into the air outlet. Please be especially careful with small children.
-  **Do Not** use this device if condensation is present. If the product is brought in from the cold to a warm area (e. g., during transport), condensation can occur within the unit. Let the device reach room temperature, before using it.
-  **Do Not** use this product on wet surfaces. Do not use this product in a bathtub, shower or locate product where it may fall into a bathtub, laundry, swimming pool or other water container.
-  **Do Not** immerse this product in water or allow water to drip into the motor housing.
-  **Do Not** use near furnaces, fireplaces, stoves or other high-temperature heat sources.
-  **Do Not** position this product too close to draperies or other loose fabrics as they may be drawn into the

product, cutting off airflow and damaging the motor.

- ⊘ **Do Not** carry this product by the cord, or use the cord as a handle as it can damage internal wiring. Do not unplug product by pulling on cord or place the cord under strain. To unplug, grasp the plug, not the power cord.
- ⊘ **Do Not** run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings.
- ⊘ **Do Not** route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over. To avoid a tripping hazard, safely coil/store the power cord.
- ⊘ **Do Not** tamper with or modify this product in any way.
- ⊘ **Do Not** allow the power cord to come in contact with water or wet locations.
- ⊘ **Do Not** place power cord near heat sources, such as heaters or radiators.

ⓘ **ELECTRICAL CONNECTION:** Only a proper 100V~50Hz / 60Hz AC outlet may be used to connect to public power supply.

DANGER

Risk from Electrical Shock. Contact with wires or components that are under voltage could be potentially fatal!

- ⊘ **Do Not** touch the product with wet or damp hands.
- ⊘ **Do Not** operate any product with a damaged cord or plug or after the product malfunctions, has been dropped or damaged in any manner. Discard product, or return to NF Imports for examination and/or repair in order to avoid a hazard.
- ⓘ If the supply cord is damaged, it must be replaced by NF Imports in order to avoid a hazard.
- ⊘ **Do Not** stretch the power cord or put the cord under strain.
- ⓘ Disconnect the fan from main power supply before removing the guard.
- ⊘ **Do Not** insert or allow foreign objects to enter any input or output opening as they may cause risk of electric shock or fire, or damage the product.
- ⓘ Turn off all controls before unplugging. Unplug from wall outlet if not in use for extended periods of time.
- ⊘ **Do Not** open appliance housing while product is plugged in. Due to the risk of electrical shock, all

servicing requests should be made with NF Imports. Only original replacement parts may be used.

- ⓘ For safety reasons, always unplug the unit in the event of a thunderstorm.

WARNING

Risk from Improper Installation: Follow all instructions to avoid personal injury and property damage.

- ⓘ Ensure that wall power outlet is easily accessible so unit can be disconnected during an emergency.
- ⊘ To reduce the risk of fire or electrical shock, do not use this product with any external (solid state) speed control device.
- ⊘ To reduce the risk of fire or electric shock and injury to persons, do not use in a window.

SAVE THESE INSTRUCTIONS

FEATURES



⚠ WARNING - Pinch Hazard between Fan Body and Kickstand.

HOW TO USE



- ⏻ Power
- 📄 Digital Display
- 🕒 Timer (1-12 hours)
- Decrease Speed / Timer
- + Increase Speed / Timer

⚠ CAUTION: TIP-OVER HAZARD. Ensure the kickstand is fully locked and resting securely on a flat surface before use. To prevent tip-over, do not operate the fan if the kickstand is extended but not properly positioned on a stable, level surface.




CLEANING

Grille Removal Screwdriver required. 

⚠ WARNING: To reduce the risk of electrical shock and injury to persons, unplug the circulator before removing grille.

1. To release the Front Grille, remove the screw located on the back of the air inlet, located roughly at the 6 o'clock position.
2. Rotate the Front Grille counter-clockwise and pull out.
3. Dust or wash the Front Grille with a mild dishwashing soap. Do not place grille in the dishwasher. The excessive heat can distort the plastic.
4. Wipe the Blade with damp cloth.



- NOTE: Blade is not removeable.
5. To reattach the Front Grille - align the Vornado logo slightly to the left and push the grille in while rotating clockwise until fully seated.

6. Replace the screw.



Use the brush attachment on your household vacuum cleaner to vacuum any accumulated dust off the Front Grille and Air Inlets.

TROUBLESHOOTING

Problem

Unit fails to power on.

Possible Cause and Solution

Unit is not plugged in. Plug Power Cord into electrical outlet.

Unit is damaged or in need of repair. Cease usage and unplug. Contact Consumer Service for assistance.

The outlet is worn or damaged. Try another outlet or contact a qualified electrician.

Unit is not producing sufficient amount of air.

Air speed setting is too low. Adjust to a higher speed setting.

Airflow is blocked. Remove obstruction.

Adjust direction of airflow toward the user.

WARRANTY

3 Year Satisfaction Guaranteed

Warranty Terms and Conditions:

Please contact the retailer where purchased or contact the authorized importer before returning the product for a warranty claim. The product warranty will be honored on models that are being used in the country intended. See the silver rating label on the product to confirm the safety testing marks which identify the specific country of intended use. Please provide a copy of your receipt with the defective product when returning to the authorized location. Repairs performed after the warranty period, are subject to a charge.

The manufacturer assumes no responsibility for damage or injury caused by failure to follow these instructions, improper product use or unauthorized product modification. Improper product use

includes using an external device that alters or converts the voltage or frequency of electricity. Such use will invalidate the product warranty. The product will be considered modified if the rating label has been removed, thus making the warranty void.

Repair by an unauthorized service center or use of non-approved replacement parts is not recommended and any consequences will not be covered by support services or product warranties.

Shipping a Vornado product to a country not intended for use, will void all warranties.

製品には万全を
期しております。

万が一不具合
がありましたら、
下記へご連絡く
ださい。

vornado.jp
0120-390-747
info@vornado.jp



Designed, engineered and supported in Andover, KS

© 2025 Vornado Air LLC Andover, KS 67002 Specifications subject to change without notice.
Vornado® is a trademark owned by Vornado Air LLC.

目次

安全上のご注意.....	15	お手入れ方法.....	20
特徴.....	18	故障かな?.....	21
操作方法.....	19	製品保証.....	22

ご使用前に必ずすべてお読みください。

安全上のご注意

本取扱説明書およびその他添付書類は、本製品の付属品であり、安全上のご注意、ご使用方法、処分方法などの重要事項が記載されています。本製品を安全に正しくご使用いただくために、ご使用前に必ずお読みください。また、これらの書類は大切に保管し、所有者が変わる際には本製品に添付してお渡しください。取扱説明書の最新版については、vornado.jpをご確認ください。

本取扱説明書では次のような注意事項を記載しています。

⚠ 危険

この欄は誤った取扱いをした際に、死亡や重傷を負う危険性の高い項目を示しています。危険防止のためこれらの警告は必ずお守りください。

⚠ 警告

この欄は誤った取扱いをした際に、死亡や重傷、傷害または物的損害を負う中程度の危険がある項目を示しています。

⚠ 注意

この欄は本製品の取扱いに関する追加の情報を示しています。

使用上お守りいただく内容を図記号で説明しています。

- ⓪ してはいけない内容を示しています。
- ❶ しなければならない内容を示しています。

使用目的: 本製品は一般家庭、オフィスなど屋内用です。業務用ではありません。この製品は床置き専用です。本取扱説明書に従わず、本製品を目的外の用途に使用された場合、または不当に製品を改造された場合に生じる損害または傷害について、メーカーは一切責任を負いません。またそのような場合、本製品に関する保証の適用外となります。

警告- 火災、感電、ケガなどを防止し、安全に正しくご使用いただくために、以下の注意事項を守ってください。

⚠ 警告

子どもや不慣れな方への危険性:

- ❶ 本製品の対象年齢は12歳以上です。安全にご使用いただくために、身体的、知覚的、精神的なハンディキャップのある方(子どもを含む)や不慣れな方がご使用にな

る場合は、責任を持てる方の指導または監督のもとお使
いください。

- お子様が本製品で遊ばないようにしてください。
- 本製品のお手入れは、お子様だけで行わないでくだ
さい。必ず責任を持てる方が付き添ってください。
- 本製品および梱包材は玩具ではありません。お子様の
手の届く場所に保管しないでください。

警告

誤った取扱いをした場合に生じる危険性：人的及び物的
損害を負わないよう次の指示に従ってください。

- 屋外や天候の影響を直接受ける環境では使用しない
でください。
- 吹き出し口に指を入れないでください。特に小さなお子
様にはご注意ください。
- 結露が生じている場合には、本製品を使用しないでくだ
さい。温度の低い環境から高い環境に移動させた場合（
配送、運搬した場合）に本体内部に結露が生じることがあ
りますので、本体が室温になってからご使用ください。
- 本製品を濡れた場所で使用しないでください。浴室、ま
た浴槽・洗濯機・プールなどの水に落ちる可能性のある
場所では使用しないでください。
- 本製品を水に浸けないでください。また、モーター部分
に水が入らないように注意してください。
- ヒーター・ストーブなどの暖房器具やコンロの熱が本

製品に当たる場所で使用しないでください。

- カーテンなどの布の近くで使用しないでください。本製
品に布が巻き込まれて空気の流れが妨げられ、モーター
が破損する恐れがあります。
- 電源コードのみを持って本製品を移動させないでくだ
さい。電源コードを引っ張ると芯線が破損する可能性が
あります。またプラグをコンセントから抜く際は、電源コ
ードを持たず必ずプラグを持って抜いてください。
- 電源コードは、絨毯の下を這わせたりラグなどの敷物
で覆ったりしないでください。
- 家具や家電機器など重いものを電源コードの上に載
せないでください。電源コードにつまづくことがないよう
に出入りの多い場所には設置しないでください。つまず
かないように電源コードをまとめたり収納したりしてくだ
さい。
- 本製品の分解、修理、改造は一切行わないでください。
- 電源コードを水や濡れた場所に触れさせないでくだ
さい。
- 電源コードを暖房器具の熱が当たる場所に置かない
でください。

● **電源**：必ず100V 50Hz/60Hzのコンセントをご使用く
ださい。

危険

火災や感電の危険性：プラグをコンセントにつないでいる
時に製品内部の銅線や部品を触ると、死亡する危険性が
あります！

- 濡れた手で本製品を触らないでください。
- 電源コードやプラグが破損した場合は、製品を使用し
ないでください。製品が誤作動した場合、または落下や
何らかの理由で破損した場合にも使用しないでくださ
い。危険を避けるために、製品を廃棄するか、(株)エヌエ
フ貿易に点検および修理を依頼してください。
- 電源コードが破損している場合は、危険を避けるため
に(株)エヌエフ貿易に修理を依頼してください。
- 電源コードを引っ張ったり押さえたりしないでくださ
い。
- カバーを取り外す前に、必ず製品のプラグをコンセ
ントから抜いてください。
- 本体の開口部に異物を入れないでください。火災や感
電、また故障の原因になります。
- 電源コードはスイッチを切ってから抜いてください。ま
た長期間使用しない場合は、プラグをコンセントから抜
いてください。
- プラグをコンセントに差し込んだまま、本体を開けな
い。感電の危険性があるため、修理はすべて(株)
エヌエフ貿易に依頼してください。純正の修理部品のみ
使用が可能です。

● 安全のため、雷雨時にはコンセントからプラグを抜いて
ください。

警告

不適切な設置をした場合に生じる危険性：人的傷害およ
び物的損害を避けるため、すべての指示に従ってください。

- 必ず、非常時にすぐに電源プラグを抜くことのできる位
置にあるコンセントを使用してください。
- 火災や感電の原因になりますので、後付けの速度調節
器を使用しないでください。
- 火災や感電、ケガの原因になりますので、本製品を窓
にはめ込まないでください。

取扱説明書は大切に保管してくださ
い。

特徴

大きく操作しやすいボタンと
デジタル表示
99段階の速度設定

取り外し可能な
カバー

床に跡が残らない足ゴム



キックスタンド(垂直を含む5段階の角度調整可能)

⚠️警告: サーキュレーター本体とキックスタンドの間に指をはさまないように注意してください。

一体型ハンドル

コード収納フック

操作方法



⏻ 電源

88 デジタル表示

🕒 オフタイマー(1~12時間)

- 風速下げる/タイマー時間短縮

+ 風速上げる/タイマー時間延長

⚠️注意: 転倒に注意。本体を平らな面に置き、使用前にキックスタンドがしっかり開いて固定されていることを確認してください。キックスタンドが開いて固定されていても、平らな面に設置されていない場合は、転倒の危険性があるためサーキュレーターを操作しないでください。



お手入れ方法

カバーの取り外し プラスドライバーが必要です。

警告: 感電や負傷を防ぐため、カバーを取り外す前にサーキュレーターのスイッチを切り、プラグをコンセントから抜いてください。

1. カバーを外すために、まず背面(時計のおおよそ6時の位置)にあるネジをプラスドライバーで外します。
2. 前面のカバーを反時計回りに回し、引き抜きます。
3. カバーはホコリを落とすか、汚れを食器用洗剤で洗ってください。食洗機には入れないでください。高温によりプラスチックが変形する可能性があります。
4. 湿った布でプロペラを拭きます。
注意: プロペラは取り外しできません。
5. Vornadoロゴが少し左に傾いた位置で、カバーを本体に載せます。カバーを時計回りに回すと、カバーが本体にはまる位置があります。さらに回すとカチッとはまり、元の位置に戻ります。
6. ネジを元通りに取り付けます。



Tip 家庭用掃除機の付属ブラシを使用して、カバーと吸気口のほこりを吸い取ります。

故障かな？

トラブル

電源が入らない。

考えられる原因と解決方法

プラグが外れていませんか。プラグをコンセントに差し込んでください。

製品が破損し修理を要する場合は、直ちに使用を中止し、(株)エヌエフ貿易までご連絡ください。

コンセントがゆるんだり、劣化したりしていませんか。
別のコンセントを試すか、専門の業者に修理を依頼してください。

空気の流れが弱い、または遅い

サーキュレーターの速度が低く設定されていませんか。速度設定を高くしてください。

空気の流れが妨げられている場合は、障害物を取り除いてください。

空気の流れを感じられるように本体の向きを調節してください。

製品保証

3年間保証付き

保証規約

製品の修理をご希望の際には、必ず事前に販売業者あるいは代理店にお問い合わせください。

製品保証は、それぞれの国で販売されているモデルにのみ適用されます。製品の銘板にある安全法適合性検査マークを見て仕様対象国をご確認ください。修理を希望する際には、必ずご購入を証明できるレシート等を提出してください。保証期間終了後の修理につきましては有料となります。

本取扱説明書に記載のない使用または不当な修理や改造(変圧器の使用

も含む)による故障や損傷については保証の適用外となり、メーカーは一切責任を負いません。故意に銘板を剥がしたとみられる場合にも、保証の適用外となります。

指定外の業者による修理や純正品以外の交換部品の使用は推奨しません。その結果により生じる不具合は、サポートサービスや製品保証の適用外となります。

本保証規約はその製品が販売されている国においてのみ有効です。

ボルネード・エア日本総代理店
(株)エヌエフ貿易
〒176-0024
東京都練馬区中村3-38-8
TEL: 0120-390-747
www.vornado.jp



カンザス州アンドーバーで設計およびエンジニアリング

© 2025 Vornado Air LLC Andover, KS 67002 U.S. 仕様は予告なく変更される場合があります。

